




Smart Lock Manual

Electronic Keypad Lock



HBUS-ZNS-H001-SIL

PREFACE

WARNING:

This Manufacturer advises that no lock can provide complete security by itself.

This lock may be defeated by forcible or technical means, or evaded by entry elsewhere on the property.

No lock can substitute for caution, awareness of your environment, and common sense.

In order to enhance security and reduce risk, you should consult a qualified locksmith or other security professional.

Warranty & After-sale Service:

We provide one year warranty and free life-time tech support.

Any question please feel free to contact us:

US Toll Free: 1-888-605-1615(Available after 7:00 PM Pacific time)


E-mail: smartlock01@hotmail.com

DIRECTORY

INTRODUCTION	01
Product Specifications	01
Package	02
Performance	03
INSTALLATION MANUAL	04
Tools Needed	04
Installation Step	04
SMART INSTRUCTION	12
Pairing Lock to Phone App	12
TT LOCK App Operating	13
MATCH the Wi-Fi GATEWAY to the APPLICATION	18
MATCH the TTLOCK APP to the ALEXA APP	19
MATCH the SMART WATCH to the SMART LOCK	21
OPERATION INSTRUCTIONS	22
Setting Admin Passcode	22
Lock/Unlock	23
Dead Lock	23
Reset	24
Battery Power Runs Out	24
FAQ	27


INTRODUCTION

Product Specifications



Item No.	H001
Material	Zinc Alloy
Weight	3.16 lb
Communication mode	Bluetooth 4.0ble
Unlocking way	Bluetooth, Code, Mechanical key Finger Print, IC Card, Alexa
Support System	Android 4.3 / IOS 7.0 above
Unlock time	≈ 1.5 sec
Power supply	4pcs AA batteries
Static current	≤30uA
Working current	≤200mA

Package



Part	Description	Quantity
A	Key	2
B	Keypad	1
C	Door Lever	1
D	Latch	1
E	Wood Screws	2
F	Strike Plate	1
G	Flat Screw	3
H	Receiver Module	1
I	Short Flat Screw	3
J	Battery Cover	1
K	Ineer Lock	1
L	IC Card	2
M	Size Reference Card	1

Performance

1.Smarter and Safer

Keyless Passcode Bluetooth unlock,Mechanical key,IC card,and auto lock (5-20s) to keep your house smarter and safer.

2.Real Time Record

Though Smart Door Locks with App (TTlocks) you can check the Unlocking Records and Know Who comes to your home.

3.Fast Sharing and Convenient


Share with Friends through App (TTlock) with smart Lock, you can share passcode can be set for one time use,permanent use,Custom time use , Recuring use.

4.Easily Install and Smart Reminder

when smart holes are in low battery smart locks will alarm and remind you , it needs to be temporary charged by a 9 V battery.

INSTALLATION MANUAL


Note: Install and test lock with door open to avoid being locked out



Tools Needed

screw driver


1.Adjusting Latch Length



Note: When performing this operation, please take protective measures and be careful of the metal edge not to injure yourself.

1.Place latch and fasten the latch to the door

2.Check Door Dimensions



1) Backset Determination

Backset is a distance from door edge to center of hole on door face.

2) Hole's Diameters

Using the marks as guide to drill holes

$\Phi 3/8''$ (10mm)----Fasten Smart door lock

$\Phi 2-1/8''$ (54mm)


3) Door Thickness

The door thickness within 1-1/2" to 1-7/8" (38mm-48mm) are all suitable for the keypad deadbolt handle set.


3. Install Lock

1) Install Latch

Note: pay attention to The locks arc direction faces the outer door



Insert the latch and ensure it is parallel to the door face.




A. Mark the outline of the faceplate ,then take out the latch.

B. Chisel 1mm-2mm deep along the outline to allow the faceplate to be aligned with the door edge.

C. Insert the latch into the door ,use 2 wood screws to secure latch.

2) Install Plate




Hole's Diameters using the manes to drill holes as guide 3/8"
Fasten Smart door Lock

Chisel 1mm-2mm deep along the plate outline to allow the plate to be aligned with the door frame.

C.Insert the plastic lock groove and the strike plate into door jamb tighten with wood screws.




3)Install Keypad



Install lever into keypad inner plate.

Place IC wire, latch link bar and double-screws through the holes on the deadbolt, as the picture on the right shows.

Note: IC wire should be placed under latch. After installing the front pad, roll the handle spindle to test if it could work with levers or not. If could not, take out the front pad and roll the latch link bar around 90 degree and try to install again untill it could work with the lever.



Pass the IC wire and the latch link bar to mounting plate.


Use 1 flat screw to secure with the keypad double-screw bolt.

Use 2 flat screw connect mounting plate with latch.


Note: Please place the IC line as shown in the figure to avoid the lock latch out of control.

4)Identify Door Handling

The door is "Left-handle" if the hinges are on the left side of the door.





Whereas the door is "Right-handle" if the hinges are on the right side of the door.





5)Install Receiver Module

Remove the battery cover (Press the spring button with the sharp object and push the cover up first then push it up)




Connect the IC wires together normally



Use 2 short flat screw tighten the receiver module inner battery groove. There is also a screw slot under the battery box

8) Insert Battery and Install Back Battery Cover



Insert 4pc (AA) 1.5V Alkaline batteries and slide the battery cover back onto the receiver module.

Remarks:

(1) Alkaline batteries are recommend in order to stabilize the power supply,if you don't use alkaline, battery performance will be reduced greatly.

(2) All settings will be retain in the memory even if the batteries are complete dead . A micro USB can directly power the lock and activate the keyboard. Charging it via the ports under the lock.

SMART INSTRUCTION

Pairing Lock to Phone App

1.Download the App " TTLock"

Android Mobile Phone--Search "TTLock" from Google Play.

Apple Mobile Phone--please search "TTLock" from App Store.




2.Register and Login the Account

The image displays three screenshots of the TTLock application interface. The first screenshot shows the 'Login' screen with a blue header bar containing 'Login' and 'Register' buttons. Below the header is a blue hand icon. The main form has fields for 'Phone number/Email' and 'Password', with a 'Login' button at the bottom. A 'Forgot Password?' link is visible. The second screenshot shows the 'Register' screen with a blue header bar containing 'Register' and 'Login' buttons. Below the header is a blue hand icon. The main form has fields for 'Country/Region' (set to 'United States +1'), 'Enter your Phone number', 'Password between 8-28 chars', 'Confirm Password', and 'Verification Code'. There is a 'Get Code' button and a 'Register' button at the bottom. The third screenshot shows the 'Login' screen with a blue header bar containing 'Login' and 'Register' buttons. Below the header is a blue hand icon. The main form has fields for 'Email' (set to 'nulink@bolik.com') and 'Password', with a 'Login' button at the bottom. A 'Forgot Password?' link is visible.

3.Match the Lock to the Application

When matching, follow the prompt steps of the program, you need to touch the screen after installing the lock and installing the battery, match the blue icon lock , and set the name for the lock.

Note: If the smart lock is in a non-addable state, Take out batteries to power off the lock about 5 seconds. Then, power on and long press manual button about 10 seconds. Once hearing beep beep sound, the lock is reset successfully.




TT LOCK App Operating


1.Account Information Change

When logging in "TTLock" App, you need set up an account contain account password.

Each account can be added with multiple smart device locks for management.

Once the smart lock is added, it will become the admin account for the lock.





2.Lock/Unlock

Press for unlock, long press for lock. It requires your smart phone and Bluetooth lock to be within a certain range.



Note: If you want remote control, you need to connect to the Gateway.

3.Send ekey

You can add another account on the app.

This way your family can also control the Bluetooth lock via the app.

Support authorized users to Limit time, Permanent, One-time, Recurring control smart lock.



4.Generate Passcode



Generate or customize the passcode of the Bluetooth lock.

Generate or customize permanent, one-time, time-limited, recurring passcode.

Note: Generate the passcode to clear the passcode that Bluetooth lock stored by "Erase". Once used, in addition to the admin passcode, other passcode will be cleared.

5.ekeys

Manage the authorized accounts in “Send eKey” .
Admin can clear eKey, reset eKey, send eKey etc.





6.Passcodes

It records all passwords stored by the Bluetooth lock you had set.
In addition, it can also reset, generate, upload passwords.

7.IC Cards

You can match two types of IC card: Permanent or Timed.
Place the card against the card reader sensor on the smart Lock(keypad panel).







8.Fingerprints

You will be required to Place and Remove your finger to the sensor several times please follow the prompts.

9.Records

It records the time and manner of the smart lock when someone opening or closing.
Manage your Bluetooth lock safely and efficiently.





10.Settings

It have the function about the Bluetooth lock function setting, lock information setting, remote unlocking, auto-off time, lock sound, time proofread, record reading, etc.

You can find the information about the lock such as battery power, admin passcode.



Note:The admin passcode will not be cleared when erase passcode.



If you forget to lock your door often, you could to set “Auto Lock” . Set the time for automatic locking in your needs, so you don't have to worry about security accidents due to being unlock.

11.Remote Control

Remote control support needs an extra additional Wi-Fi Gateway. Match the gateway, smart phone, app then the smart lock can support remote control lock.






MATCH the Wi-Fi GATEWAY to the APPLICATION

Remote Control and Aleax would support after matching the Wi-Fi Gateway.

Click the button in the upper left corner of the page and enter relevant information as prompted to add a gateway to your account.

Note: When the smart phone app matches the smart lock or the gateway, it is necessary to enable Bluetooth and Wi-Fi. It can be successfully matched when your smart phone is close to the lock and the Gateway.







MATCH the TTLOCK APP to the ALEXA APP

After setting up to the gateway, authorize the TTLock app in the Alexa app and log in to the TTLock account to enable remote unlock and voice remote unlock.


Select "Skill & Games", input "TTLock" in the search bar, click "ENABLE TO USE". And input TTLock account and password to finish the authorization.

Note: If shows "Invalid Account and Password", please add "+1" at front of the account.





Press locks option, choose the lock you paired. Click the icon in the upper right corner and slide the icon button of “unlock by app” and “unlock by vocie” .



MATCH the SMART WATCH to the SMART LOCK



Apple watch
Android watch

Support Smart Watch (Apple watch or Android watch) lock/unlock.

It is supported that smart watch match to smart phone.

If the watch is connected to the phone, but it cannot search the "TTLock" App.

Try to log in to the home page at your phone app, to refresh, and then check in the watch.


If all settings are normal but can't lock/unlock.

Opening the "TTLock" App in your phone to check if the key is in a normal state.

Note:All the operations, your watch and mobile phone require a certain range, the mobile phone network and Bluetooth need to remain in a normal state.

OPERATION INSTRUCTIONS

keep the door opened while programming to avoid being locking out accidentally.




Setting Admin Passcode


Via App:

TTLock - Settings - Basics - Admin Passcode

Via keypad (when not added to the phone):

Enter [*12#123456#Custom Admin passcode#Confirm Admin passcode#] in keypad.





Lock/Unlock

Via Key: The package contains two keys that can be used directly through the keyhole.

Via Keypad: Enter the passcode then press “#” to unlock. Long press “#” and hold 2s for lock. (No password required)

Via APP: Touch to unlock, long press to lock. It supports at a certain distance between smart phone and lock

Note: Remote control support need to matching with Wi-Fi Gateway.

Reset

1. Take out one of the battery to power off the lock about 5 seconds. Then put in the battery, power on the lock and long press the button about 10 seconds.

Once hearing "Please enter the initialization password", please enter "000#" to confirm.

You will receive a voice prompt after reset successfully.

2. Long press and hold the reset button in back panel for 10 seconds.


Once hearing "Please enter the initialization password", please enter "000#" to confirm.

You will receive a voice prompt after reset successfully.

Battery Power Runs Out

The smart lock will sound an alarm when the battery power is low.

A micro USB can directly power the lock and activate the keyboard. Charging it via the ports under the lock.



FREQUENTLY ASKED QUESTIONS

Please refer to the Instructions Guide if have any detail questions for these FAQs.
If necessary, please contact our customer service.

INSTALLATION FAQ

Q1. Why does the latch is stuck?

A1. The locking tongue is stuck with IC line. Please check and place the IC line inside mounting plate correctly by viewing manual or install video.

A2. (if only work with mechanical key)

1.Please make sure the spindle part is works properly after passing through the deadbolt. If you can't use the APP or keypad to control unless insert a key(lock is stuck), please help to check: re-install after rotate the spindle by 90 degree.

2.Then check the direction of the knob. Make sure that it is in horizontal for Left handle and in vertical for right handle when in unlock status.

Q2. How to lock/unlock via keypad?

A2. Long press “#” and hold for 2s to lock the door, and enter the passcode and press “#” to unlock the door.

Q3. Operates backwards. Smart lock will unlock when you locked it, and will lock when you unlocked it.

A3. Please find the toggle button inside the back panel, then switch it to another side. (If it is right handle door, please set to R. If it is left handle door, please set to L.)

Q4. How to open the keyhole cover?

A4. Find the dots on both side of the keyhole cover, and use 2 pins to press them at the same time. The keyhole cover will pop up.

Q5. How to unlock if battery power runs out?

A5. A micro USB can directly power the lock and activate the keyboard. Charging it via the ports under the lock.

Q6. How to set the admin passcode?

A6.

Via App: TTLock - Settings - Basics - Admin Passcode

Via keypad (when not added to the phone): Enter

[*12#123456#Custom Admin passcode#Confirm Admin passcode#] in keypad.

Application FAQ

Q1. How to do if I cannot match the door lock (the name is gray) in the TTLock?

A1. Try to reset the lock. Please find the reset button on page 23 of the manual. And follow the steps on page 24 to reset the lock.

Q2. How to set the account password?

A2. TTLock - Upper left corner(menu button) -Settings - Click on your profile picture(edit) - Reset Password.

Q3. How to set/check the admin passcode?

A3. TTLock - Settings - Basics- Admin Passcode.

Q4. How to set auto lock time?

A4. TTLock - Settings - Auto Lock. Please Calibrate Time in [Lock Clock] and Enter the [Firmware Update] to confirm that your APP is the latest version.

Q5. What is [Send e-key]?

A5. Send e-key to authorize to other accounts. The recipient also needs to download TTLock and register an account. Recipients will have permission to control the lock via their phone APP.

Q6. How to Erase/Edit the guest passcode?

A6. Erase: Generate Passcode - Erase- Click Generate - Enter this passcode on the keyboard and all guest passwords will be erased. Edit: Passcodes - Click on a code - You can edit in [Passcode].

Other FAQ

Q1. Does it support Wi-Fi connection(Remotely unlock)?

A1. Yes it supports to Wi-Fi connection. Please note that it needs to match the gateway (sold separately).

Q2. How to get a compatible gateway?

A2. G1 or G2 gateway could compatible with our door lock. Or, contact us for more recommendations.

Q3. What if I forget my TTLock account password?

A3. You can reset the user password through [Forgot Password] in the login interface.

Q4. How many different passcodes/fingerprint/ IC card can I set?

A4. You can set only one admin passcode but you can generate/paring at least 150 guest passwords/fingerprint/ IC card. Please note: For security reasons, the guest passcode needs to be activated within a certain period of time (used at least once), otherwise it will be invalid.

Q5. Can I remotely share / generate a guest passcode?

A5. Yes you can generate remotely and share the passcode even far away from the door lock (without Wi-Fi).

Q6. Can I use one IC card to match different door locks?

A6. Yes you can use one IC card to match different door locks. Please note it will become very dangerous once the IC card is lost, so we do not recommend it.